How to Order Ink/Toner for a Brother Laser Printer

A complete tutorial on ordering and installing toner cartridges for your Brother laser printer

OVERVIEW

Brother Laser Printers

Brother is a Japanese electronics company known for reliable multifunctional inkjet and laser printers. Their laser printers use toner cartridges containing dry ink powder instead of traditional liquid inks, producing sharp, high-resolution prints at reasonable prices.

These printers feature user-friendly touchscreens, versatile connectivity options, and capabilities for printing, scanning, copying, and faxing.

STEP 1

Before You Order

Printer Model Name

Locate your Brother printer model name on the device

Toner Type

Identify the specific toner type your printer requires

Cartridge Number

Note the cartridge number from your current toner (starts with "TN")

STEP 2

Ordering Your Toner Cartridge

01

Visit Brother's Website

Go to brother-usa.com/supplies/ink-and-toner in your browser

02

Search for Your Cartridge

Enter your printer model name or cartridge number in the search bar

03

Apply Filters

Use the left sidebar to filter for laser printers and genuine cartridges

04

Add to Cart

Click "Add to cart" below your selected toner cartridge

05

Review Your Order

Go to cart icon, adjust quantity if needed, then click "Proceed to Cart"

STEP 3

Complete Your Purchase

1

Enter Personal Details

Provide your full name, email address, phone number, address, city, state, and ZIP code

2

Select Shipping Method

Choose standard ground, 2-day, or next day delivery (charges vary by method and distance)

3

Payment Information

Enter card number, expiration date, CVV, or add PayPal account details

4

Place Your Order

Review total amount including shipping charges and complete payment



INSTALLATION

Setting Up Your Toner Cartridge

Power On & Open Access Door

Turn on printer and open the access door at the front or on scanner unit

Remove Old Cartridge

Gently pull out the old cartridge if one is installed

Prepare New Cartridge

Unbox cartridge, remove seal, and move it back and forth gently (don't shake vigorously)

Install & Secure

Match color sticker to slot, insert following arrow direction until it clicks, then close cover firmly

TROUBLESHOOTING

Common Installation Issues

Low Toner Warning After Installation

Cause: Cartridge not installed properly or non-genuine product

Solution: Check proper installation and verify cartridge is from Brother's official website or authorized seller

Toner Cartridge Fit Issues

Cause: Access door won't close due to bulky design or incorrect installation

Solution: Verify cartridge compatibility and reinstall correctly until it clicks into place

Printer Not Detecting Cartridge

Cause: Cartridge not seated properly, protective tape not removed, or incompatible cartridge

Solution: Check compatibility, ensure proper seating in color-coded slot, and remove all protective tape

KEY FACTS

Important Information

6

Months

Average lifespan of opened Brother toner cartridges

2

Years

Shelf life of unopened toner cartridges

TN

Prefix

All Brother toner cartridge numbers start with "TN" (e.g., TN-223, TN-450)

FAQ

Frequently Asked Questions

Can I use the same toner for different Brother models?

No, each cartridge has a different build specific to printer models. Using the wrong cartridge won't fit and will cause errors.

Where can I check the cartridge number?

Check the cartridge label inside the printer. It's printed on the front or side, usually starting with "TN."

Is third-party toner safe to use?

Compatible toner may work but isn't always recommended due to quality concerns. Use genuine cartridges from official sources.

GET HELP

Need Assistance?

If you're unable to resolve cartridge-related issues on your own, our experts can help with toner cartridge installation and troubleshooting for Brother laser printers.

Visit **reconnectofflineprinter.com/contact-us** to enter your name, email address, phone number, and describe your issue. Our team will get back to you soon.